

## AC Circuits

### Single-Phase AC


The Watt's Law formulas for DC circuits also apply to single-phase (1 $\phi$ ) AC circuits containing only resistance.

If inductance or capacitive reactance puts the circuit out of phase, the power factor must be added to the basic power formula:  $P = I \times E \times PF$

### Three-Phase AC

The formula for a three-phase (3 $\phi$ ) system includes another term called the "three-phase factor", which is a constant equal to the square root of 3, or 1.73.  $P_{3\phi} = I \times E \times PF \times 1.73$

## Transformer

<p><b>Step Down Transformer</b></p>  <p>Primary      Secondary</p> <p>1000V      200V 2 A      10 A 2000 W      2000 W</p> <p>50 turns      10 turns</p> <p>Core</p>	$E_S = E_P \times \frac{N_S}{N_P}$ <p><math>N_P</math> = number of turns of the primary <math>N_S</math> = number of turns of the secondary</p>
---	---

## Reactance Formulas

### Inductor

$$X_L = 2\pi f L (\Omega) \quad \text{Where } L \text{ is in Henrys}$$

### Capacitor

$$X_C = 1 / 2\pi f C (\Omega) \quad \text{Where } C \text{ is in Farads}$$

## Impedance Formula

$$Z = \sqrt{R^2 + (X_L - X_C)^2} \quad \text{in Ohms (for series circuit)}$$